DATALOGIC AUTOMATION

DATAVS2 SERIES

The **DATAVS2** vision sensor series presents all the characteristics able to solve artificial machine vision applications in a flexible and intuitive way. DATAVS2 is a completely embedded device: the optic, the red LED illuminator and the electronics are included in an extremely compact housing. The sensor is configured via PC through Ethernet communication. The configuration software is included in the product and it has been developed in order to lead the customer through the configuration process step by step. DATAVS2 is available in three different versions according to the installed control tools: Object Recognition (OBJ), Advanced Object Recognition (AOR) and Identification (ID). Many different control typologies are available: brightness, contrast, position, width, count, pattern match, contour match, 360° pattern match, barcode and datamatrix reader, OCV.







HIGHLIGHTS

- · Flexible and intuitive setup via PC through Ethernet
- · Memorisation of 20 inspections
- 11 different controls
- 360° pattern match for Advanced models
- · Logical operators: AND, OR, NOT, NAND, NOR, etc.
- TURBO mode to double elaboration speed
- VSM compatibility

APPLICATIONS

DATAVS2 is ideal for the control of text presence in overprinting and logo position on food packages, product completeness before packaging, logo position on cosmetic bottles, correct stamp on post envelopes, liquid level inside a plastic bottle, correct product orientation on a conveyor belt, barcode and datamatrix reading.

Part orientation

Stamp control



Level control





Overprinting



Barcode & Datamatrix



The extremely compact size of the DATAVS sensors is not an obstacle for the full integration of all the elements for a reliable image-based control.


- · Compact housing
- Red light LED illuminator
- Selectable lenses
- Focus knob
- Standard M12 connectors
- Ethernet communication
- 3+1 PNP outputs
- 4 signalling LEDs: output1, output2, power supply, communication
 • Teach push-button
- 640x480 pixel greyscale image sensor







DIMENSIONS



INDICATORS AND SETTINGS

Teach push-button with double function:

- reference image update
- recovery mode




- A Power supply, green
- B Digital output 1, orange
- C Digital output 2, orange
- D Network connection, green

CONNECTIONS




M12 4-pole Ethernet



- 1 = white/orange = RX+
- 2 = white/green = TX+
- 3 = orange = RX-
- 4 = green = TX-

M12 8-pole (power supply and I/O)



OBJ and AOR models

- 1 = white = digital input 1
- 2 = brown = 24 Vdc
- 3 = green = configurable output
- 4 = yellow = output 1
- 5 = grey = output 2
- 6 = pink = output 3
- 7 = blue = GND
- 8 = red = external trigger

ID models

- 1 = white = RS232 RX
- 2 = brown = 24 Vdc
- 3 = green = configurable output
- 4 = yellow = output 1
- 5 = grey = output 2
- 6 = pink = RS232 TX
- 7 = blue = GND
- 8 = red = external trigger

TECHNICAL DATA

Power supply:	24 Vcc ±10 %		
Ripple:	1 Vpp max with illuminator 2 Vpp without illuminator		
Consumption:	100 mA at 24 Vdc (without illuminator)		
Output type:	3+1 PNP		
Output current:	100 mA max		
Saturation voltage:	< 2 V		
Network interface:	M12 4-pole Ethernet 10/100 Mbs		
Serial interface:	RS232 (only ID models)		
External illuminator interface:	Strobe signal (24 V PNP N.O.)		
Frame rate:	60 fps		
Optics:	integrated (6 mm / 8 mm / 12 mm / 16 mm)		
Setting:	TEACH push-button		
Indicators:	4 LED		
Connections:	M12 8 pole A-code M12 4 pole D-code		
Mechanical protection:	IP50		
Protection devices:	A, B		
Housing material:	aluminium alloy / ABS		
Weight:	125 g		
Operating temperature:	-10 +50°C		
Storage temperature:	-25 +70°C		

TECHNICAL NOTES

¹Limit values


²A - reverse polarity protection B - overload and short-circuit protection






FIELD OF VIEW

OPERATING	FIELD OF VIEW (Width x Height) in mm					
DISTANCE (mm)	DATAVS2-16-xx-xxx	DATAVS2-12-xx-xxx	DATAVS2-08-xx-xxx	DATAVS2-06-xx-xxx		
50	-	17 x 12	25 x 20	42 x 30		
80	-	25 x 20	40 x 30	60 x 41		
110	-	33 x 25	55 x 40	80 x 55		
140	31 x 24	45 x 35	70 x 50	98 x 69		
170	39 x 29	53 x 38	85 x 60	118 x 83		
200	46 x 34	60 x 50	100 x 70	138 x 92		
300	70 x 53	90 x 65	145 x 103	201 x 140		
400	94 x 71	121 x 82	186 x 132	265 x 189		
500	118 x 89	150 x 110	236 x 167	330 x 232		
600	143 x 107	185 x 130	282 x 232	385 x 270		





Step 1: Image Setup




The first step consists in connecting the sensor and configuring the image quality parameters. When the desired results are obtained, the user can memorise the image that will be used as a template during sensor functioning.

Step 2: Teach



The second step establishes the acceptance criteria to distinguish objects from wastes. One or more controls can be selected according to the task to carry-out.

Step 3: Run



The third step configures the sensor digital outputs, simulates sensor functioning on the PC to verify the controls chosen and activates the operating phase on the sensor using the PC only to control the diagnostics.

MAXIMUM SIMPLICITY




Discovery

The Discovery function finds all the sensors connected to the network.



Help


A Help is available for each step, supplying useful suggestions on the options available.



Inspection explorer

All the parameters connected to the inspection are grouped together and can be easily reached by the user.


Inspection selection



Each inspection is composed of a template and parameters. A specific inspection can be thus referred to different products in progress on the same production line.


The different inspections can be recalled using digital pulses or through an Ethernet or RS232 command. Different inspection selection protocols with or without acknowledge are available.

Statistics



The statistics panel displays all the information about inspection results and execution time. Data can be shown also in a graph.

Image saving



The image saving panel allows to set a folder where the acquired pictures are stored. An image saving condition can be also specified.

CONTROL TABLE

Object Recognition

Seven different controls able to cover the most varied applications.					
Control	Functioning	Applications	Image		
Pattern Match	Searches a sample inside a specific area	Packaging: logo check Assembling: product orientation Post automation: stamp check	BEAUTY AND Cream C		
Contour Match	Shape control	Metal working: integrity control Food: coffee waffle shape control			
Position	Check of object border position				
Width	Measures object width	Assembling: plastic part control Wood industry: branch thickness measurement			
Counting	Counts the objects along a line	Electronics: component counting Pharmaceutical: blister stack counting			
Contrast	Contrast calculation	Food: date and lot presence control Metal working: laser marking control	COMMISSION OF THE COMMISSION O		
Brightness	Brightness calculation	Bottling: cap presence control Packaging: object counting	900 900 900		

ADVANCED MODELS (AOR)

The Advanced Object Recognition (AOR) models integrate new important functionalities, including:



360° Pattern Match locator Object detection independent from rototranslations.



Logical tools
Possibility to
combine the results
of the single tools
through boolean
operator (AND, OR,
NOT, etc.)



Advanced Ethernet Current inspection results available also on Ethernet communication.



Speed-up High execution speed thanks to the management of reduced resolution and TURBO mode.

360° Pattern match

The Advanced Object Recognition (AOR) models include all the controls and locators available on Object Recognition models as well as the new 360° Geometric Pattern Match Locator.










IDENTIFICATION MODELS (ID)

Control	Functioning	Image
Barcode reader	Decode: read and decode one (or more) barcode in the Region Of Interest. String match: read and decode one (or more) barcode and compare it with a set of reference strings. Counter: count the number of barcodes in the Region Of Interest.	
Datamatrix reader	Decode: read and decode one (or more) datamatrix in the Region Of Interest. String match: read and decode one (or more) datamatrix and compare it with a set of reference strings. Counter: count the number of datamatrix in the Region Of Interest.	Gedruc mit krat. Zweidin
ocv	Verify the readability of printed characters	Manufacture perferibilitects entre 109 10 11 Manufacture April 1822

Symbologies

Codabar	0 12345 67890 5	UPC-A
Code 39		UPC-E
Code 128		PDF417
EAN-8		Pharmacode
	ladladdalladaldalladadladdalladlaadlaad	Postnet
EAN-13	արգինոկիների Արկաների Արկանի ա	IMB
Interleaved 2 of 5		ECC200





MODEL SELECTION TABLE

MODEL	SOFTWARE	LOGICAL TOOLS	ETHERNET	RS232	I/O	OPTIC	ORDER N°
DATAVS2-06-DE-OBJ	Object Rec.		Base		2 IN; 4 OUT	6mm	959951050
DATAVS2-08-DE-OBJ	Object Rec.		Base		2 IN; 4 OUT	8mm	959951060
DATAVS2-12-DE-OBJ	Object Rec.		Base		2 IN; 4 OUT	12mm	959951070
DATAVS2-16-DE-OBJ	Object Rec.		Base		2 IN; 4 OUT	16mm	959951030
DATAVS2-06-DE-AOR	Adv. Obj. Rec.	•	Advanced		2 IN; 4 OUT	6mm	959951000
DATAVS2-08-DE-AOR	Adv. Obj. Rec.	•	Advanced		2 IN; 4 OUT	8mm	959951010
DATAVS2-12-DE-AOR	Adv. Obj. Rec.	•	Advanced		2 IN; 4 OUT	12mm	959951020
DATAVS2-16-DE-AOR	Adv. Obj. Rec.	•	Advanced		2 IN; 4 OUT	16mm	959951040
DATAVS2-06-RE-ID	Identification	•	Advanced	•	1 IN; 3 OUT	6mm	959951130
DATAVS2-08-RE-ID	Identification	•	Advanced	•	1 IN; 3 OUT	8mm	959951140
DATAVS2-12-RE-ID	Identification	•	Advanced	•	1 IN; 3 OUT	12mm	959951120
DATAVS2-16-RE-ID	Identification	•	Advanced	•	1 IN; 3 OUT	16mm	959951190

ACCESSORY SELECTION AND ORDER INFORMATION

MODEL	DESCRIPTION	ORDER N°
CV-A1-36-B-03	M12 8-pin shielded cable 3m	95A255430
CV-A1-36-B-05	M12 8-pin shielded cable 5m	95A255440
CV-A1-36-B-10	M12 8-pin shielded cable 10m	95A255450
DATAVS-ST-5068	L-shaped fixing bracket for 90° mounting	95A901320
DATAVS-ST-5066	U-shaped fixing bracket for angle adjustment	95A901330
DATAVS-CV-RJ45C-03	3 m crossed Ethernet cable	95A901340
DATAVS-CV-RJ45D-03	3 m direct Ethernet cable	95A901350
DATAVS-MK-01	Mounting kit	95A901380











The company endeavours to continuously improve and renew its products; for this reason the technical data and contents of this catalogue may undergo variations without prior notice. For correct installation and use, the company can guarantee only the data indicated in the instruction manual supplied with the products.

Rev. 05, 01/2011 9C502500E